# Support Information

#### Nintendo Customer Service

#### Nintendo Customer Service

Australia: (03) 9730 9822 New Zealand: 0800 743 056

Hours of operation: 9:00am to 5:00pm Monday to Friday (AEST/AEDT).
Call charges vary. Check with your telecommunications provider.

Email: warrantyadmin@nal.nintendo.com.au

#### Pat. pend.

© 2017 Nintendo Co., Ltd. Trademarks are property of their respective owners. Nintendo 2DS and Nintendo 3DS are trademarks of Nintendo.



Manufacturer: Nintendo Co., Ltd., Kyoto 601-8501, Japan Importer in Australia: Nintendo Australia Pty. Ltd., 804 Stud Road, Scoresby, Victoria 3179, Australia





# **Operations Manual**

Nintendo may change product specifications and update this information from time to time. The latest version of the manual is available at http://support.nintendo.com

#### Health and Safety Information

Please read and observe the health and safety information. Failure to do so could result in injury or damage. Adults should supervise the use of this product by children.

### MARNING – Seizures

- Some people (about 1 in 4000) may have seizures or blackouts triggered by light flashes or patterns, and this may occur while they are watching TV or playing video games, even if they have never had a seizure before. Anyone who has ever experienced seizures, loss of awareness or any other symptom linked to an epileptic condition should consult a doctor before playing video games.
- Stop playing and consult a doctor if you have any unusual symptoms, such as: convulsions, eye or muscle twitching, loss of awareness, altered vision, involuntary movements, or disorientation.
- To reduce the likelihood of a seizure when playing video games:
  - Do not play if you are tired or need sleep.
  - Play in a well-lit room.
- Take a break of 10 to 15 minutes every hour.

#### MARNING – Eye Strain, Motion Sickness and Repetitive Motion injuries

- Avoid excessively long play sessions.
- Take a break of 10 to 15 minutes every hour, even if you don't think you need it.
- Stop playing if you experience any of these symptoms:
  - · If your eyes become tired or sore, or if you feel dizzy, nauseated or tired;
  - If your hands, wrists, or arms become tired or sore, or if you feel tingling, numbness, burning or stiffness or other discomfort.

If any of these symptoms persist, consult a doctor.

# MARNING – Battery

- Stop using if the battery is leaking.
- If battery fluid comes into contact with your eyes, immediately rinse your eyes with plenty of water and consult a doctor. If any fluid leaks on your hands, wash them thoroughly with water. Carefully wipe the fluid from the exterior of the device with a cloth.
- This product contains a lithium-ion battery. Do not replace the battery yourself. The battery must be removed and replaced by a qualified professional. Please contact Nintendo Customer Service for more information.

#### MARNING – Electrical Safety

- Use only the AC adapter (WAP-002) to charge the system.
- Connect the AC adapter to the correct voltage (AC 230-240V).
- Do not use voltage transformers or plugs that deliver reduced amounts of electricity.
- The AC adapter should be plugged into a nearby, easily accessible electrical outlet.
- The AC adapter is for indoor use only.
- If you hear a strange noise, see smoke or smell something strange, unplug the AC adapter from the electrical outlet and contact Nintendo Customer Service.
- Do not expose devices to excessive force, fire, microwaves, high temperatures or direct sunlight. Do not pull on cables and do not twist them too tightly.
- Do not let devices come into contact with liquid and do not use in extremely humid places. Do not use them with wet or oily hands. If liquid gets inside, stop using and contact Nintendo Customer Service.
- Do not touch device connectors with your fingers or metal objects.
- Do not touch the AC adapter or connected devices while charging during a thunderstorm.
- Use only compatible accessories that have been approved for use in your country.

Do not disassemble or try to repair devices.
 If devices are damaged, stop using them and contact Nintendo Customer Service. Do not touch damaged areas.
 Avoid contact with any leaking fluid.


#### MARNING – General

- Keep this system, its accessories and packaging materials away from young children. Small parts such as Game Cards, microSD cards and packaging Items may be swallowed. The cables can coil around the neck.
- Do not use this system within 25 centimetres (10 inches) of a cardiac pacemaker while using wireless communication. If you have a pacemaker or other implanted medical device, first consult a doctor.
- Wireless communication may not be allowed in certain places such as aeroplanes or hospitals.
   Please follow respective regulations.
- Do not use excessive volume for headphones.
  This may damage your hearing. Keep the volume at a level at which you can hear your surroundings.
  Consult a doctor if you experience symptoms such as buzzing in your ears.

#### CAREFUL USAG

- Do not place the system in humid areas or areas where the temperature can suddenly change. If condensation forms, turn the power off and wait until the water droplets have evaporated.
- If devices become dirty, wipe them with a soft, dry cloth. Avoid using thinner, benzene or alcohol.
- Be aware of your surroundings while playing.
- Make sure to charge the built-in battery at least once every six months.
  If the battery is not used for an extended period of time, it may become impossible to charge it.

#### **Getting Started**





(label facing upwards)

microSD card slot

Note: A microSD card will already be inserted.

# IMPORTANT INFORMATION FOR PARENTS PLEASE READ!

Your system offers a variety of exciting features, but not all of them may be suitable for children. We have prepared special steps to help make your system safe for your child.

During the initial setup of your system, you will be asked to set Parental Controls. Touch SET to begin, then follow the on-screen instructions. You can set various restrictions, including restricting software by age rating, preventing internet access, restricting shopping services, preventing image/video sharing, preventing online interaction and more. Choose a PIN code to ensure that your child cannot change the settings you made.

To use Parental Controls or to change the settings after the initial setup has been completed, open the System Settings from the HOME Menu and select PARENTAL CONTROLS.

In addition, you can restrict your child's use of Nintendo Network." services from PCs, smartphones and other devices. This option will be offered automatically when a Nintendo Network ID is first created or linked, and can be changed at any time by touching ACCESS FROM PCS AND OTHER DEVICES in the Nintendo Network ID Settlings. Please also make sure that you have set up a PIN code in Parental Controls as detailed above to ensure that your child cannot make changes to settlings.

#### If you own another Nintendo 3DS system...

It is recommended that you transfer data to your new system before you play.

#### CAUTION

If you use software on this system before transferring data from your old Nintendo 3DS™ system, any save data created for downloadable or built-in software on this system will become unusable after the transfer.

Also, if you link a new Nintendo Network ID to this system, it will no longer be possible to transfer data from a system linked to a different Nintendo Network ID.

For more information about performing system transfers, please visit the Nintendo Support website at **support.nintendo.com** 

# **Activating and Deactivating Wireless Communication**

To activate or deactivate wireless communication and near-field communication (NFC), touch 👶 in the upper-left corner of the Touch Screen while on the HOME Menu to open the HOME Menu Settings, then touch ON or OFF under Wireless Communication/NFC.

# **Warranty Information**

For warranty information, see support.nintendo.com



For more information about New Nintendo 2DS™ XL, please visit the Nintendo Support website.

support.nintendo.com